

ANTI-GERM® PRATIC NF

Pre and Post milking chlorhexidine based product for teat disinfectant

PURPOSE

Anti-Germ® PRATIC NF is a ready to use liquid disinfectant, designed for pre and post teat treatment by automatic robot spraying.

Anti-Germ® PRATIC NF could also be use by manual spraying or with a soaker cup For after milking application, teats rinsing is not needed. The teats must be washed before the next milking.

For before milking application, teats need to be wiped.

ADVANTAGES

- Efficient in 1-minute contact time on bacteria present on teats (EN1656)
- · Contains cosmetic agents, softeners and moisturizers
- · Easy and economic to use
- Environment friendly
- · Could be use in organic farming

COMPONENTS

• Chlorhexidine Digluconate (N° CAS: 18472-51-0): 3 g/kg

PHYSICOCHIMICAL PROPERTIES (20°C)

Aspect Pink Limpid Liquid

pH in ready to use solution: ≈ 5.7

Density at 20°C: ≈ 1,02 g/cm³
Gel Temperature: < -5°C

REGLEMENTATION

ANTI-GERM® PRATIC NF is a ready-to-use liquid TP3 disinfectant under the rule (EU) N° 528/2012 concerning the making available on the market and use of biocidal products.

MODE OF USE

Milking robot

- 1. Put the canister
- 2. Insert the cannula

Anti-Germ France SAS
Z.I. Le Roineau
F-72500 VAAS
Phone +33 (0) 2 43 46 71 22
Fax +33 (0) 2 43 46 70 05
info@Anti-Germ.fr
www.Anti-Germ.com/fr



ANTI-GERM® PRATIC NF

By spraying or soaker cup

- 3. Fill the sprayer tank or the soaker cup tank with ANTI-GERM® PRATIC NF.
- 4. Apply on teats.

When ANTI-GERM® PRATIC NF is applied before milking, teats need to be wiped

BIOCIDES PROPERTIES

TP3 USE [Teats disinfection]

Norm	Strains	Test conditions & Result	
Bactericidal efficacy on	Escherichia coli	Temperature: 30°C	≥ 5
the teats according to	Staphylococcus aureus	Interfering agent: skimmed milk 1 %	Success
EN1656 standard	Streptococcus uberis	Contact time: 1 min	

PRECAUTIONS FOR USE AND STORAGE CONDITIONS

Before use, we recommend to read the safety data sheet.

PRECAUTIONS

- · Avoid to release into the environment
- Keep out of reach of children.
- · For professional use.

STORAGE

- Keep Anti-Germ® PRATIC NF out of frost.
- · Keep container tightly closed.

PACKAGING

Canisters: 20, 60, 200 kg

USE BIOCIDES PRODUCTS CAREFULLY. BEFORE ANY USE, READ THE LABEL AND PRODUCT INFORMATION.

Further information can be obtained by consulting the safety data sheet. The content of this documentation does not engage our responsibility. The application must be adapted to each particular case. The values given are indicative only and have in any case specification value. Anti-Germ commercial service is available for any information regarding the product.

Anti-Germ France SAS
Z.I. Le Roineau
F-72500 VAAS
Phone +33 (0) 2 43 46 71 22
Fax +33 (0) 2 43 46 70 05
info@Anti-Germ.fr
www.Anti-Germ.com/fr